

HD EKO 10

ELEVATOR CONTROL CARD

USER MANUAL

HEDEFSAN

PARAMETER LIST

00	Elevator Type	19	Fire Stop
01	Command Type	20	Park Stop
02	Door Type	21	Return to Park
03	Automatic Door at Floor	22	Busy Time
04	Automatic Door at Park	23	Wait at Stop
05	One Door Full Automatic	24	Door Open Time
06	Special Door Setting	25	Lock Waiting
07	Number of Stops	26	Door Still Open Error
08	Cabin Serial Card	27	Photocell Waiting
09	Phase Protection	28	Fast Cruising
10	Phase Leve	29	Slow Cruising
11	Ptc	30	RP Delay
12	Contact Feedback	31	Plug Delay
13	Position reset	32	Lock Delay
14	Limit Switch	33	Maintenance Time
15	Digital Setting	34	Change Password
16	Display Exit	35	Counter Type
17	Max. Car Call Registration	36	Factory Settings
18	Number of Basement		

TECHNICAL SPECIFICATIONS

Dimensions Lenght × Width × Hight (mm)	181 × 150 × 22
Operation Temperature	±0 - +60 °C
Protection Class	IP20
Humidity	%95
Network Control Inputs	3 x 380V, 50Hz, N
Control Feed Voltage	24 ± 5 Vdc
Power Usage	Max. 400mA 10W, for 24VDC
Security Circuit Voltage	230Vac max. For hydraulic elevators in emergency descent 24Vdc
Control Signal Inputs	24 ± 5 Vdc
Control Signal Outputs	24 ± 5 Vdc Short circuit protected



GENERAL FEATURES

- 2-line 16-character LCD display and 4 button keyboard
- RS-485 serial communication for group operation
- RS-485 serial communication for serial system connection with cabin
- Including phase sequential motor protection circuit
- Including in- and output control of 2 automatic doors
- Short circuit protected digital and signal outputs
- Setting of indicator possible via menu: 7-segment and Gray code

OPENING SCREEN

HEDEFSAN HD-EKO
Ver_1.9

When you power on, you can view the software version and serial number of the card on the opening screen. After a couple a seconds the screen changes to the MAIN SCREEN.

MAIN SCREEN

Waiting for recording...
D:10 +25.4V

Here it shows the feed voltage and the number of the floor where the elevator is at the present.

ELEVATOR TYPE

00:Lift Type
Double Speed

Set your elevator drive type here

One Speed	Choose this setting for single speed roped elevators.
Double Speed	Choose this setting for double speed roped elevators.
Roped VVVF	Continous gear (with asynchronous machine) and gearless (with synchronous machine)

COMMAND TYPE

01:Command Type
Simple Command

Set your elevator command type here.

Simple Command	The cabin and floor buttons are connected parallely. No other expect the one registration is kept in memory.
Mixed Collective	The cabin and floor buttons are connected parallely. Registrations are kept in memory.
Down Collective	The cabin and floor buttons are connected seperately. Cabin registrations are collected from both sides. Floor calls are collected when when cabin moves in downward direction.
Full Collective (both ways)	Cabin registrations and the up and down buttons at the floors are connected seperately. Cabin registrations and floor calls are collected in appropriate manner of movement direction.

DOOR TYPE

02:Door Type
Swing Door

Set the open-close signal type for automatic doors here.

Swing Door	Only for elevators that have no automatic door.
Aut. Unlimited	Only used for elevators with automatic unlimited cabin doors.
Aut. limited	Only used for elevators with automatic limited cabin doors.
Full Aut. Unlimited	Only used for elevators with full automatic unlimited cabin doors.
Full Aut. limited	Only used for elevators with full automatic limited cabin doors.



- According to the EN 81-1/2 standards in states of emergency stop, revision and take back automatic doors must remain stationary

AUTOMATIC DOOR AT FLOOR

03:Aut. Door. At. Floor
Closed Standby

Set the open or closed position of the automatic door when waiting at floor.

AUTOMATIC DOOR AT PARK

04: Aut. Door. At. Park
Wait closed

Set the open or closed position of the automatic door when waiting at park.

ONE DOOR FULL AUTOMATIC

05:One Door
Full Aut. Cancel

On elevators with swing doors, set this parameter when there's only one full automatic door.

SPECIAL DOOR SETTING

06:Special Door Setting
Floor:10 Door:AB

Set the floor at which you want to open the automatic A and B doors. When floor number is blinking, change the floor number with the UP-DOWN buttons till you come to the floor number you want to change. Press the ENTER button and next you will see the door setting blinking. A-B Determine the door setting again by using the UP-DOWN buttons.

NUMBER OF STOP

07:Number of Stops
D:10

Set the number of stops (maximum 10) here

CABIN SERIAL CARD

08:Cabin Serial Card
19200 Baud

Set the communication speed between the main controller card and the serial communication card here. Or choose to ignore it

PHASE PROTECTION

09:Phase Protection
Phase Sequence

Set the phase sequence or deactivate the phase here.

Out of Order	Deactivate phase
Phase unsequenced	Activates phase without sequence
Phase sequenced	Activates phase sequenced.

PHASE LEVEL

10:Phase Level
030

Adjust the phase imbalance here..

020 - 060	These are the minimum and maximum phase balance time
------------------	--

PTC

11:Ptc
Active

Choose the PTC motor thermistor input setting.

ACTIVE	Activates it
CANCEL	Deactivates it.

CONTACT FEEDBACK

12:Contact Feedback
Active

Set here the bypassing of the contact feedback error. The controller card does not detect any contactor adhesion when it's cancelled. If it is canceled our company is not responsible.

ACTIVE	Activating the contact feedback error
CANCEL	Bypassing the contact feedback error

POSITION RESET

13:Position Reset
Cancel

Even when there's a power blackout the controller card will remember its last position. But in some special cases when the power returns, a position reset may be wanted. In that case the elevator will go until it reaches the 817 limit switch of the bottom floor. When it reaches the bottom floor, the floor counter will reset. For example: with systems that have battery charged rescuers, this parameter can be activated to reset the position.

ACTIVE	Position Reset Activates it.
CANCEL	Position Reset Deactivates it.

REVISION LIMIT SWITCH

14:Rev. Limit Switch
Until limit switch

Set the movement type of the up and down limit switches in revision.

Until Limit switch	When limit switches are enabled the elevator will stop before reaching its floor.
Until Floor	Even when limit switches are enabled the elevator will go to its floor.

DIGITAL SETTING

15:Digital Setting
FLOOR:1 IND:1

When the floor number is blinking, set the floor number with the UP-DOWN buttons till you come to the floor number you want to change. Press the ENTER button and next you will see the digits blinking. Set the value you like. When finished exit with the exit button. Or if you want to set another stop/floor, press the enter button, when floor number is blinking, repeat the steps.

Indicator type	Outputs that can be selected
7 Segment indicator	-4, -3, -2, -1, 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10 A, B, C, D, E, F, H, J, L, N, O, P

DISPLAY OUTPUT

16:Display Output
Normal

Set the display output of the HD EKO-10 controller card and HD EKO SERI card.

7 Segment output	Normal output.
Gray code output	Gray code output.

MAX. CALL REGISTRATION

17:Max. Call Reg.
010

Set the maximum amount of calls that can be registered from within cabin. When this number is reached it stops registering any calls from within cabine.

01 - 10	Set the number of stops between the minimum and maximum..
---------	---

NUMBER OF BASEMENT

18:Number of basement
000

Set the number of basement here.



If the elevator is down collective, the floors that are under the basement that is set, it will be up collective.
Note: Used in command types except for down collective.

FIRE STOP

19:Fire Stop
01

Set here the fire stop. When Fire input (at YAN) is active the elevator goes to the defined floor directly and waits with its doors open. Elevator will return to normal operation mode when fire signal is over

01 - 10 Seconds	This is the minimum and maximum time that is waited before going to park stop.
Cancel	Fire stop is not defined in the system.

PARK STOP

20:Park stop
05

Set the park stop here. When elevator pauses its operation, it goes to this floor and waits with open doors.

RETURN TO PARK

21:Return to Park
200 Seconds

Set the waiting time before going to park stop.

0 - 250 Seconds	Set the waiting time between the minimum and maximum.
-----------------	---

BUSY TIME

22:Busy Time
006 Seconds

Set the cabin light delay here.

5 - 20 Seconds	Set the cabin light delay time between the minimum and maximum.
----------------	---



According to the EN 81-1/2 standards it is not allowed to bypass the cabin light delay.



On elevators with simple command (non-collective) this parameter must be equal to the "WAIT AT STOP" time. And the busy time must be at least 2 seconds.

WAIT AT STOP

23:Waiting Time at Floor
008 Seconds

Set the waiting time before going to other registrations while collecting.

3 - 15 Seconds

Set the waiting time at floor between the minimum and maximum



According to the EN81-1 and EN81-2 standards, elevators with manual doors must have a waiting time of at least 2 seconds when moving again after reaching its floor



On elevators with simple command (non-collective) this parameter must be equal to the "CABIN LIGHT" time and must be at least 2 seconds.

OPEN DOOR TIME

24:Open Door Time
15 Seconds

Set the time from opening till closing of the automatic door.

05 - 20 Seconds

Set the door open-close time between the minimum and maximum.

LOCK WAITING TIME

25:Lock waiting
008 Seconds

Set the maximum time to wait for the door lock signal (140) after getting the door closed signal.

8 - 30 Seconds

Set the lock waiting time between the minimum and maximum.

DOOR STILL OPEN ERROR

26: Door Still Open Error
015 Seconds

If after the time set in this parameter the door is not closed yet the control panel will go out of service. It is possible to choose to bypass this function.

0 - 250 Seconds

Set the time for passing the door still open error between the minimum and maximum.

FOTOSEL BEKLEME SÜRESİ

27: Photocell Waiting time
003 Seconds

Set the time of waiting for the photocell signal to close the door after the opening of the automatic door.

02 – 05 Seconds

Set the photocell waiting time between the minimum and maximum.

FAST CRUISING

28: Fast Cruising
015 Seconds

Set the maximum time of cruising between 2 stops. If this time should be exceeded, the system automatically stops the movement of the cabin and blocks it.

0 - 100 Seconds

Set the fast cruising time between the minimum and maximum.



According to the EN81-1 / 2 standards motor operation time work must not exceed the smaller of the following:

- o 45 seconds
- o Longest cruising distance +10 seconds
- o If longest cruising distance is less than 10 seconds, the timeout should be at least 20 seconds

SLOW CRUISING

29: Slow Cruising
015 Seconds

Set the maximum time of slow cruising from the moment it meets the stopper of the target floor. If this time should be exceeded, the system automatically stops the movement of the cabin and blocks it.

0 - 100 Seconds

Set the slow cruising time between the minimum and maximum.

RP DELAY

30: RP Delay
02600

It could be demanded with roped VVVF systems to delay the fall of the main contactor. In such cases, the RP delay of the relay output is set by this parameter.

00000 – 25000 Milliseconds

Set the contactor delay time between the minimum and maximum

PLUG DELAY

31: Plug delay
00600

Set here the waiting time after the 130 circuit.

00000 – 25000 Milliseconds

Set the plug delay time between the minimum and maximum

LOCK DELAY

32: Lock Delay
00100 Miliseconds

Set the maximum waiting time for arrival of the lock (140) signal after the door closed signal.

0 - 2000 Miliseconds

Set the lock delay time between the minimum and maximum.

MAINTENANCE TIME

33: Maintenance Time
32 Days

For every day the card operates the value of this parameter drops by one. For example, if it is set for 45 days, this parameter will Show a value of 15 when 30 days have passed. After 45 days the value will be 0.

45-250 Days

Set the maintenance time between the minumum and maximum.

CHANGE PASSWORD CODE

34:Change Password

Set or change the password code here.

1_0_0_0_0

If the display looks like this, the password is activated.

COUNTER TYPE

35:Counter Type
M0

Set here your selection of the elevator floor sensor.

Standart M0

Standard M0 counter.

Standart M1


Standard M1 counter.

FACTORY SETTINGS

36:Factory Settings

Here you can cancel your settings and return to factory settings.



HD Eko 10 Control Card Key Names

Key	Description	
R S T	Main Supply	
MP	Mains Neutral	
1	Cabine Feed input	
2	Cabine Light Feed	
K3	Door Close Signal	
K5	Door Open Signal	
K15	Common signal of door open and door close	
KN	Safety Circuit Neutral	
120	Stop Circuit	 Maks. 230Vac
130	Door Plug Contact Circuit	
140	Door Lock Circuit	
M0	Floor counter magnetic switch input	
142	142 Signal	
KRC	Feedback Input of the main contactor. The normally closed contacts of the 100 signal of the main contactor must be connected serially to this entry	
S1A-S1B	Cabin Serial Communication Terminals (With HD EKO SERIAL cards)	
100	Control Circuits Feed (+24Vdc)	
1000	Control Circuits Feed (0V)	
PTC	As long as there is motor thermistor & panel thermostat signal	

HD Eko 10 Card Relay Outputs

Key	Description
11	Common RU1, RU2, RH, RF Contactors Feed Voltage
RU2	Up Direction Contactor
RU1	Down Direction Contactor
RH	High Speed Contactor
RF	Low Speed Contactor

HD Eko 10 Jumper Connection

3-jumper connection on the HD Eko 10 Card	
	
If 31, 32, 02 and 12 signal outputs are 100	If 31, 32, 02 ve 12 signal outputs are 1000

HD KLS Card Key Names

Key	Description
869	Revision Key (from the Revision Box)
500	Revision Downward Button
501	Revision Upward Button
FRI	Fire Alarm Contact
DEP	Earthquake Alarm Contact
DTS	Door Close Button
K20	Door Open Button & Door Jam & Photocell Contact
804	Overload Contact
817	Down Obligatory limit Magnetic Switch
818	Up Obligatory limit Magnetic Switch
869P	Revision Key (to Controller Card)
2G	7-Segment Indicator Outputs
190	Common Simple Command Output
X1-X10	In/Out Controller Recorder Inputs
31	Downward Arrow Light
32	Upward Arrow Light
2	Out of Service Lights
12	Busy Lights

Magnetic Switch and Magnets SETUP

Standard M0 counter system: Used in double speeds elevators where the declaration distance is smaller than half of the distance between two floors.

Drive Type	Cabin Positioning Sensor	Early Door Opener Levelling	Magnetic Switch	Magnet
Double Speed	Standard M0 Counter	Not applicable	M0 (Bi-stable)	Round Magnet

M0 Counter System SETUP


On M0 counter system the cabin movement and floor information is detected with 2 types of magnetic switches.

- Floor counter and decelerating magnetic switch (SM0, Bi-stable)
- Floor stopper magnetic switch (SJF, Bi-stable) On this counter system bi-stable magnetic switches and round magnets are used. M0 is used as the floor counter and also as the decelerator. JF (142) switch works as the floor stopper.
- For the magnet arrangement please consult the connections diagrams.
- Connect the switch ends of the M0-100 and 142-100 terminals respectively.




SAFETY NOTES


An elevator (an elevator with safety measures such as an overload system and with automatic doors according to the standards) is risk free for its user and it falls upon elevator industrial companies like us and companies that take care of the installation and maintenance like yours to reduce any chance of risk of an accident to remissible levels. In the following some basic safety points are discussed in relation to the elevator control system. Please pay attention to all these measures to safely operate our lifts, and hence minimizing any risk of an accident. In order for the lift system to be according to the EN 81-1 / 2 standard, the control card, the control panel and electrical connections must be appropriately done. HEDEFSAN guarantees the compliance of the control card to the standards. But the control panel internal connections, external connections and other electrical connections are the responsibility of the installer. Do not pass the safety circuit in any way through a relay or contact. Hide the connectors of the plug and lock circuits connections in the door's free space in a way that it won't touch the door chassis. Take into account that water can flow from upper floors when the stairway is being cleaned and that also there could be liquid spillage inside the cabin. Therefore if possible the safety connections should be put into isolated boxes. If this it not possible they must be insulated with insulation tape. Door frames must be bounded to the grounding bus bar of the panel. When the grounding is not done, it is possible that the safety circuit is bypassed through the door frame. Years of operation, dust, dirt, oil may cause the loss of functionality of the safety circuit. Do not forget to check the plug and lock functions on the periodic maintenance. HD Eko 10 safety circuit operates with 220Vac voltage. The motor contactors are fed directly from the safety circuit. In this way it prevents involuntary movements outside the control of safety circuits.



HEDEFSAN		HD EKO 10 HD DRIVER		HD EKO 10		HD EKO 10		HD EKO 10	
R S T IMP		U V W		110 120 130 140		100 1000 PTC		100 1000 PTC	
GROUP OTOMAT		POMPA PUMP		KAYMAK AKUMARÖLÜSÜ LEAKAGE RELAY		FRENZ/BRAKE		FRENZ/BRAKE	
2000 2400 2800 3200		35A-1000V		220VACV		220VACV		220VACV	
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	
REV TARİHİ:		REV TARİHİ:		REV TARİHİ:		REV TARİHİ:		REV TARİHİ:	
TARİH: 22.01.2021		VERSİYON: 1.2		VERSİYON: 1.2		VERSİYON: 1.2		VERSİYON: 1.2	
www.hedefsan.net		www.hedefsan.net		www.hedefsan.net		www.hedefsan.net		www.hedefsan.net	
Sayfa: 1		Sayfa: 1		Sayfa: 1		Sayfa: 1		Sayfa: 1	
Toplam Sayfa: 1		Toplam Sayfa: 1		Toplam Sayfa: 1		Toplam Sayfa: 1		Toplam Sayfa: 1	



HEDEFSAN	HD EKO 10 MAGNET LAYOUT FOR M0	DATE: 08.04.2021	Version: 1.0	www.hedefsan.net	Page: 1
	DRAWN: TAYYIP BARAN	Rev Date:	Model: HD Eko 10	Total Page: 1	Next Page:



HEDEFSAN	HD EKO 10 MAGNET LAYOUT FOR M1	DRAW: TAYYIP BARAN	Date: 08.04.2021	Version: 1.0	www.hedefsan.net	Page: 1
			Rev Date:	Model: HD Eko 10	Total Page: 1	Next Page:



EVERYONE NEEDS AN ASSISTANT!

You can download the application on the all android and app store shops as free...

- Project and documents
- Encoder dividing rate
- Error codes and solutions
- Hedefsan Web

Download



Download



KONYA FABRİKA

Büsan Özel O.S.B. Fevzi Çakmak Mh. Demir Cd. Doruk Sanayi Sit.
No:15/D 42050 Karatay / KONYA

İSTANBUL ŞUBE

Şerifali Mh. Türker Cd. Burhan Sk.
No:21/A Ümraniye/İSTANBUL

ALANYA ŞUBE

Cumhuriyet Mh. 1409. Sk. Seher Sitesi
A Blok No:11/A Merkez/ALANYA

HEDEFSAN



(0850)

455 1 413

hedefsan.net